


The RDD100.1RFS consists of a wireless room thermostat RDD100.1RF and an RCR100RF receiver. These units allow you to set the ideal room temperature at the time you want.

RDD100.1RF



1 Display

	Indicates that batteries need to be replaced
	Comfort mode
	Economy mode
	Frost protection (heating) active
245	Room temperature, setpoint, etc.
	Room temperature in degrees Fahrenheit
	Room temperature in degrees Celsius
	Button lock activated
	Display of zone (default = 1)
	Heating On
	Current room temperature

2 Change operating mode

3 Decrease value

4 Increase value

5 Battery holder

RCR100RF



6 Indication of data transmission and operating state (LED)

7. Initialization of wireless communication with transmitter (LEARN button)

Do you want to lock the buttons?



Press and hold for at least 7 seconds to activate a button lock. Repeat to unlock. The unit operates normally when the buttons are locked, but no changes can be made.

Do you want to change the operating mode?



The room thermostat provides Comfort mode and Economy mode . Changeover between the operating modes can be made manually by pressing .

Comfort mode is a permanent (24 h) selection of Comfort. Select this mode when you want to maintain permanently the Comfort temperature. It is used during occupancy periods, for example.

Economy mode is a permanent (24 h) selection of Economy. Select this mode when you want to maintain permanently the Economy temperature. It is used during non-occupancy periods, for example at night.



Note:

Frost protection is a function always active in the background. As soon the room temperature falls below 5 °C, the unit automatically activates heating .

Energy saving tips without loss of comfort

- Use Economy mode during longer periods of non-occupancy

Are your rooms too warm/too cold?

+ - ↻	Press + or - to increase or decrease the room temperature setpoint in increments of 0.5 °C/1 °F. Proceed as follows: <ul style="list-style-type: none">Press + or - to change the setpoint temporarily.Press ↻ to save the setting or wait for the program to exit automaticallyTo permanently change the temperature setpoints, use parameters P05 and P07. To lock the setpoints, use parameters P06 and P08
-------------	--

Do you want to pair transmitter and receiver?

+ - ↻ Learn	The RDD100.1RF communicates with the RCR100RF at a frequency of 433 MHz. To pair transmitter and receiver, proceed as follows: RCR100RF receiver setting: <ol style="list-style-type: none">Press and hold the LEARN button on the receiver for at least 3 seconds and then release it.Red and green LEDs flash alternately to indicate that the receiver is in learning mode. RDD100.1/RF transmitter setting: <ol style="list-style-type: none">On the transmitter, set the parameters (refer to section "Do you want to change parameters?").Check to ensure that parameter P19 is not 0, because this would mean that the wireless function is disabled. By default, parameter P19 is 1.Proceed to parameter P20. Press ↻ and parameter P20=0 (OFF) flashes. Adjust the value by pressing + to change to P20=1 (ON), then press ↻ to confirm.During wireless learning, the LCD displays "rF" and "Lrn". Wait for time out, and the transmitter exits the parameter setting mode. Successful wireless learning: <ol style="list-style-type: none">The green LED on the RCR100RF flashes for 10 minutes to indicate that the receiver has successfully completed wireless learning. Recommendation: <ol style="list-style-type: none"><i>Additional test to ensure the wireless signal is fine:</i> On the RDD100.1/RF, change the operating mode by pressing ↻ or change the setpoint by pressing + or -. On the RCR100RF, the green LED should flash for 3 seconds before changing to constantly green. At the same time, observe your radiator, boiler or heater indication (if it has one) to ensure that it changed the operating mode.If step 7 or 8 is working fine, this means you have successfully paired the units. Unsuccessful wireless learning: <ol style="list-style-type: none">If the RCR100RF fails to receive wireless data, the red LED starts to flash **. Repeat steps 1 to 8 until pairing is successful. Note: <p>Always start receiver learning before starting pairing with the transmitter. The units must be placed such that transmitter and received signals have limited external wireless interference. **In normal operation, if a drop in wireless communication occurs due to unforeseeable noise, just leave the receiver and it will recover automatically. The pairs are saved even if there is a power shut down. Communication restarts automatically after several minutes without any user action.</p>
----------------------	--

Do you want to change parameters?

+	If you want to change control parameters, proceed as follows:
-	
↶	<ul style="list-style-type: none"> Press + and - simultaneously for 5 seconds Release the buttons and parameter P02 is displayed Press + or - to scroll to the parameter that needs to be changed Press ↶ to select the parameter Press + or - to change the value Press ↶ to confirm and save the changed value Select and change other parameters The program automatically returns to the normal screen after a timeout

Parameter list

Parameter no.	Description	Setting range (default)
P02	Selection of °C or °F	1 = °C (default) 2 = °F
P03	Standard temperature display	1 = room temperature (default) 2 = setpoint
P04	Temperature sensor calibration	-3...3 °C Step 0.5 °C (-6...6 °F, step 1 °F) Default: 0 °C
P05	Comfort setpoint	5...35 °C, step 0.5 °C (41...95 °F, step 1 °F) Default: 20 °C, 68 °F
P06	Comfort setpoint lock	0 = OFF (default) 1 = ON → locked according to setting in P05
P07	Economy setpoint	5...35 °C, step 0.5 °C (41...95 °F, step 1 °F) Default: 16 °C, 61 °F
P08	Economy setpoint lock	0 = OFF (default) 1 = ON → locked according to setting in P07
P09	Buzzer	0 = OFF 1 = ON (default)
P10	Show frost protection icon	0 = OFF (default) 1 = ON and always on at 5 °C
P19	Sequential number of room unit	0 = no display of zone (RF off) 1 = zone number 1 (for standard RF) (default) ... 6 = zone number 6
P20	RF learn	0 = OFF (default) 1 = ON
P21	Scanning rate for the capacitive buttons Note: Shorter scanning rate means shorter battery life	0.2 = 0.25 s 0.5 = 0.5 s 1.0 = 1.0 s (default) 1.5 = 1.5 s
P22	Reload factory settings	0 = OFF (default) 1 = reload
P23	Software version information	No adjustment possible

Receiver's LED indication

State of receiver	State of LED
Power up (or reset)	The red and green LEDs flash alternately for 5 seconds, then change to constantly red. Note: If the receiver was previously programmed, it shows immediately constantly red.
Learning mode	The red and green LEDs flash alternately. Successful learning mode If RCR100RF learning is successful, the green LED will flash for 10 minutes.
Signal ok and output status change	The green LED is constantly lit, and if the output status changes, the green LED flashes for 3 seconds, then changes back to constantly green.
Fail to receive wireless data	If the RCR100RF fails to receive wireless data, the red LED will start to flash after 125 minutes. If the RCR100RF signal is recovered, it will return to the previous LED state.